


Frequenz - Umformer TYP FU 6 (U, C, D)  
 Frequency - Converter TYPE FU 6 (U, C, D)



Litze	Buchse
W	1
V	2
U	3
4	4
5	5
6	6
10	7
9	8
8	9
7	10

Litze	Buchse
W	1
V	2
U	3
4	4
5	5